

James Thomas 1905425

27/5/22
ACMA6007

Q3

a) The shellside type design typically leads to higher fouling rates due to the proximity of tubes within the heat exchanger with the constant variation in temperature difference with expansion and contraction causes ~~fouling~~ erosion

b) 4 mechanisms,