

**University of Wales Trinity St. David**

**School of Engineering**

**Lab report**

**Snasloy D'Silva**

**2321317**

**BEng Motorsports Engineering Year 1**

**17 March 2024**

**ACHA4012: Motorsport/Vehicle Technology**

## **Table of content**

**Introduction**

**Apparatus**

**Results**

**Graphs**

**Conclusion**

**References**

# Engine Performance Characteristics

## Introduction:

The aim of this dynamometer test is to attach an engine to a dynamometer and obtain the corrected values for the power generated from the engine, the torque, the BMEP (Brake Mean Effective Pressure), the SFC (Specific Fuel Consumption) as well as the overall thermal efficiency of the engine.

A dynamometer is used in this experiment to display different values for different criteria regarding an engine. The dynamometer being used in this experiment is specifically the SCHENCK W230. This specific dynamometer has a maximum load of 230KW and can rev up to a maximum of 10000 revolutions per minute (Abdullah et al. 2009). The string gauge communicates with the computer to read the voltage being passed through. The dynamometer is attached with the help of a drive shaft to a D16 1.6 litre v-tec Honda engine. This engine was manufactured between 2000 to 2001 and is commonly found in a Honda Jazz. The dynamometer records the throttle input into the engine. The dynamometer also has various sensors that help record the temperature of the coolant as well as the speed or revs.

In this experiment, we used two dials to test the dyno cell. The two dials are the dynamometer and the engine dial. The dynamometer dial controls the current flowing into the machine whereas the engine dial controls the rpm or the throttle response. The current flowing into the engine is the torque adjusted by the dynamometer dial. The dyno cell measures various criteria like fuel pumps, coolant pumps, ignitions and so on.

In the step test and the sweep test, the dyno controls the speed. In step test, when the throttle is controlled by the operator rotating the engine dial, it helps determine the fuel, air different specific areas. Step testing provides accurate readings while the operator maintains the engine throttle speed. In the sweep test, you get the values of the power input, the horsepower is also visible.

## Apparatus:

We consider the efficiency to be 1.

Diameter = 815.776 mm

Radius =  $D/2 = 0.407888$  m

Torque =  $(f \cdot r)/n$

Angular Velocity =  $(2\pi \cdot \text{dyno speed})/60$

Power = torque \* angular velocity

SFC = fuel flow rate / power

BMEP = brake power / displacement volume

Ambient temperature = 27 (Celsius)

## Results:

| Load    | Dyno Speed | Fuel Flow Rate | Lambda  | Angular velocity | Torque      | Power      | SFC         | BMEP       |
|---------|------------|----------------|---------|------------------|-------------|------------|-------------|------------|
| Newtons | rpm        | l/min          | Lambda  | $\omega$         | BHP         | KW         | Corr (T)    | Corr (KW)  |
| 102.275 | 1000       | 0.0704         | 1.2658  | 104.6666667      | 41.71674526 | 4366.35266 | 1.61233E-05 | 4284.48355 |
| 102.756 | 1050       | 0.0724         | 1.26783 | 109.9            | 41.91293933 | 4606.23203 | 1.57178E-05 | 4519.86518 |
| 103.689 | 1100       | 0.0737         | 1.27344 | 115.1333333      | 42.2934988  | 4869.3915  | 1.51354E-05 | 4778.09041 |
| 104.209 | 1150       | 0.0728         | 1.28476 | 120.3666667      | 42.50560066 | 5116.25746 | 1.42292E-05 | 5020.32763 |
| 105.811 | 1200       | 0.0744         | 1.29181 | 125.6            | 43.15903727 | 5420.77507 | 1.3725E-05  | 5319.13554 |
| 107.51  | 1250       | 0.07895        | 1.29729 | 130.8333333      | 43.85203892 | 5737.30842 | 1.37608E-05 | 5629.73389 |
| 109.488 | 1300       | 0.079          | 1.29895 | 136.0666667      | 44.65884138 | 6076.57968 | 1.30007E-05 | 5962.64381 |
| 111.797 | 1350       | 0.0796         | 1.29469 | 141.3            | 45.60065471 | 6443.37251 | 1.23538E-05 | 6322.55928 |
| 114.268 | 1400       | 0.0835         | 1.2855  | 146.5333333      | 46.608546   | 6829.7056  | 1.2226E-05  | 6701.64862 |
| 115.783 | 1450       | 0.0847         | 1.27818 | 151.7666667      | 47.22649632 | 7167.40792 | 1.18174E-05 | 7033.01902 |
| 116.985 | 1500       | 0.08865        | 1.2795  | 157              | 47.7167777  | 7491.5341  | 1.18334E-05 | 7351.06783 |
| 117.788 | 1550       | 0.0932         | 1.27766 | 162.2333333      | 48.04431174 | 7794.38884 | 1.19573E-05 | 7648.24405 |

|             |      |         |             |             |            |                |                 |                |
|-------------|------|---------|-------------|-------------|------------|----------------|-----------------|----------------|
| 118.47<br>1 | 1600 | 0.0959  | 1.2823<br>5 | 167.4666667 | 48.3228992 | 8092.4748<br>6 | 1.18505E-<br>05 | 7940.7409<br>6 |
| 118.77<br>2 | 1650 | 0.09875 | 1.2902<br>8 | 172.7       | 48.4456735 | 8366.5678<br>2 | 1.18029E-<br>05 | 8209.6946<br>7 |
| 118.65<br>6 | 1700 | 0.10005 | 1.2994<br>2 | 177.9333333 | 48.3983585 | 8611.6812<br>6 | 1.16179E-<br>05 | 8450.2122<br>4 |
| 118.86<br>1 | 1750 | 0.10305 | 1.3105<br>3 | 183.1666667 | 48.4819756 | 8880.2818<br>6 | 1.16044E-<br>05 | 8713.7765<br>7 |
| 119.58<br>4 | 1800 | 0.1093  | 1.3149      | 188.4       | 48.7768786 | 9189.5639<br>3 | 1.18939E-<br>05 | 9017.2596      |
| 119.93<br>4 | 1850 | 0.11415 | 1.3184<br>9 | 193.6333333 | 48.9196394 | 9472.4728<br>4 | 1.20507E-<br>05 | 9294.8639<br>8 |
| 120.17<br>6 | 1900 | 0.11745 | 1.3189<br>2 | 198.8666667 | 49.0183483 | 9748.1155<br>3 | 1.20485E-<br>05 | 9565.3383<br>6 |
| 120.94<br>8 | 1950 | 0.12055 | 1.3148<br>4 | 204.1       | 49.3332378 | 10068.913<br>8 | 1.19725E-<br>05 | 9880.1217<br>1 |
| 122.15<br>7 | 2000 | 0.12555 | 1.3165<br>3 | 209.3333333 | 49.8263744 | 10430.321      | 1.2037E-05      | 10234.752<br>5 |
| 122.84<br>5 | 2050 | 0.12785 | 1.3209<br>8 | 214.5666667 | 50.1070014 | 10751.292<br>3 | 1.18916E-<br>05 | 10549.705<br>5 |
| 123.79<br>6 | 2100 | 0.1309  | 1.3228<br>7 | 219.8       | 50.4949028 | 11098.779<br>6 | 1.17941E-<br>05 | 10890.677<br>5 |
| 124.79<br>4 | 2150 | 0.13435 | 1.3216<br>4 | 225.0333333 | 50.9019751 | 11454.641<br>1 | 1.17289E-<br>05 | 11239.866<br>6 |
| 125.13<br>7 | 2200 | 0.1377  | 1.3165<br>2 | 230.2666667 | 51.0418807 | 11753.243<br>7 | 1.17159E-<br>05 | 11532.870<br>4 |
| 126.02<br>8 | 2250 | 0.14105 | 1.3046<br>5 | 235.5       | 51.4053089 | 12105.950<br>2 | 1.16513E-<br>05 | 11878.963<br>7 |
| 126.66      | 2300 | 0.14495 | 1.2964<br>6 | 240.7333333 | 51.6630941 | 12437.028<br>8 | 1.16547E-<br>05 | 12203.834<br>6 |
| 126.82<br>2 | 2350 | 0.14985 | 1.2822<br>9 | 245.9666667 | 51.7291719 | 12723.652      | 1.17773E-<br>05 | 12485.083<br>5 |
| 126.69      | 2400 | 0.1537  | 1.2730<br>4 | 251.2       | 51.6753307 | 12980.843<br>1 | 1.18405E-<br>05 | 12737.452<br>3 |
| 126.55<br>2 | 2450 | 0.15565 | 1.2698<br>4 | 256.4333333 | 51.6190422 | 13236.843      | 1.17588E-<br>05 | 12988.652<br>2 |
| 126.43<br>8 | 2500 | 0.1596  | 1.2744<br>6 | 261.6666667 | 51.5725429 | 13494.815<br>4 | 1.18268E-<br>05 | 13241.787<br>6 |


|             |      |         |             |             |            |           |                              |                |
|-------------|------|---------|-------------|-------------|------------|-----------|------------------------------|----------------|
| 126.23<br>9 | 2550 | 0.1626  | 1.2787<br>6 | 266.9       | 51.4913732 | 5         | 13743.047<br>1.18314E-<br>05 | 13485.365<br>4 |
| 126.16<br>1 | 2600 | 0.16805 | 1.2763<br>4 | 272.1333333 | 51.459558  | 14003.861 | 1.20003E-<br>05              | 13741.288<br>6 |
| 125.84<br>7 | 2650 | 0.17145 | 1.2802<br>7 | 277.3666667 | 51.3314811 | 8         | 14237.641<br>1.2042E-05      | 13970.686      |
| 124.91<br>1 | 2700 | 0.17465 | 1.2837<br>1 | 282.6       | 50.949698  | 6         | 14398.384<br>1.21298E-<br>05 | 14128.414<br>9 |
| 123.92<br>7 | 2750 | 0.1784  | 1.2812      | 287.8333333 | 50.5483362 | 1         | 14549.496<br>1.22616E-<br>05 | 14276.693      |
| 123.68<br>9 | 2800 | 0.18005 | 1.2744<br>8 | 293.0666667 | 50.4512588 | 3         | 14785.582<br>1.21774E-<br>05 | 14508.352<br>6 |
| 123.38<br>9 | 2850 | 0.1831  | 1.2603<br>6 | 298.3       | 50.3288924 | 6         | 15013.108<br>1.2196E-05      | 14731.612<br>8 |
| 122.51<br>9 | 2900 | 0.1879  | 1.2531      | 303.5333333 | 49.9740299 | 9         | 15168.783<br>1.23873E-<br>05 | 14884.369<br>2 |
| 121.83<br>7 | 2950 | 0.19255 | 1.2394<br>3 | 308.7666667 | 49.6958503 | 15344.422 | 1.25485E-<br>05              | 15056.714<br>1 |
| 121.70<br>9 | 3000 | 0.199   | 1.2273<br>5 | 314         | 49.6436406 | 1         | 15588.103<br>1.27661E-<br>05 | 15295.826<br>2 |
| 121.12<br>3 | 3050 | 0.20605 | 1.2193      | 319.2333333 | 49.4046182 | 15771.601 | 1.30646E-<br>05              | 15475.883<br>4 |
| 121.12<br>4 | 3100 | 0.21005 | 1.2069<br>2 | 324.4666667 | 49.4050261 | 1         | 16030.284<br>1.31033E-<br>05 | 15729.716<br>3 |
| 120.85<br>1 | 3150 | 0.21605 | 1.1927<br>4 | 329.7       | 49.2936727 | 9         | 16252.123<br>1.32936E-<br>05 | 15947.396<br>6 |
| 120.59<br>6 | 3200 | 0.21795 | 1.1848<br>1 | 334.9333333 | 49.1896612 | 2         | 16475.257<br>1.32289E-<br>05 | 16166.346<br>1 |
| 120.84      | 3250 | 0.22305 | 1.1737<br>8 | 340.1666667 | 49.2891859 | 1         | 16766.538<br>1.33033E-<br>05 | 16452.165<br>5 |
| 121.63<br>3 | 3300 | 0.2255  | 1.1611<br>8 | 345.4       | 49.6126411 | 2         | 17136.206<br>1.31593E-<br>05 | 16814.902<br>4 |
| 122.18<br>1 | 3350 | 0.2285  | 1.1510<br>4 | 350.6333333 | 49.8361637 | 2         | 17474.220<br>1.30764E-<br>05 | 17146.578<br>6 |
| 122.93<br>3 | 3400 | 0.2342  | 1.1411<br>7 | 355.8666667 | 50.1428955 | 1         | 17844.185<br>1.31247E-<br>05 | 17509.606<br>6 |
| 123.47<br>5 | 3450 | 0.23605 | 1.1266<br>9 | 361.1       | 50.3639708 | 9         | 18186.429<br>1.29795E-<br>05 | 17845.434<br>3 |

|             |      |         |             |             |            |                |                 |                |
|-------------|------|---------|-------------|-------------|------------|----------------|-----------------|----------------|
| 123.42<br>8 | 3500 | 0.24195 | 1.1197<br>5 | 366.3333333 | 50.3448001 | 18442.978<br>4 | 1.31188E-<br>05 | 18097.172<br>6 |
| 124.20<br>5 | 3550 | 0.24545 | 1.1062<br>2 | 371.5666667 | 50.661729  | 18824.209<br>8 | 1.30391E-<br>05 | 18471.255<br>9 |
| 124.06<br>6 | 3600 | 0.25505 | 1.0969<br>7 | 376.8       | 50.6050326 | 19067.976<br>3 | 1.33758E-<br>05 | 18710.451<br>7 |
| 123.96<br>7 | 3650 | 0.25755 | 1.0940<br>1 | 382.0333333 | 50.5646517 | 19317.382<br>4 | 1.33326E-<br>05 | 18955.181<br>5 |
| 123.81<br>5 | 3700 | 0.26445 | 1.0965<br>9 | 387.2666667 | 50.5026527 | 19557.994      | 1.35213E-<br>05 | 19191.281<br>6 |
| 123.76<br>7 | 3750 | 0.2651  | 1.0980<br>8 | 392.5       | 50.4830741 | 19814.606<br>6 | 1.3379E-05      | 19443.082<br>7 |
| 123.50<br>9 | 3800 | 0.2693  | 1.0990<br>7 | 397.7333333 | 50.377839  | 20036.945<br>8 | 1.34402E-<br>05 | 19661.253<br>1 |
| 122.67<br>2 | 3850 | 0.27375 | 1.1053<br>3 | 402.9666667 | 50.0364367 | 20163.016<br>1 | 1.35768E-<br>05 | 19784.959<br>6 |
| 122.15<br>7 | 3900 | 0.2759  | 1.1170<br>4 | 408.2       | 49.8263744 | 20339.126      | 1.3565E-05      | 19957.767<br>4 |
| 121.18<br>4 | 3950 | 0.28285 | 1.1225<br>9 | 413.4333333 | 49.4294994 | 20435.802<br>7 | 1.38409E-<br>05 | 20052.631<br>4 |
| 120.00<br>4 | 4000 | 0.28455 | 1.1246<br>1 | 418.6666667 | 48.9481916 | 20492.976<br>2 | 1.38852E-<br>05 | 20108.732<br>9 |
| 118.73<br>4 | 4050 | 0.2871  | 1.1222      | 423.9       | 48.4301738 | 20529.550<br>7 | 1.39847E-<br>05 | 20144.621<br>6 |
| 117.44<br>2 | 4100 | 0.28895 | 1.1239<br>4 | 429.1333333 | 47.9031825 | 20556.852<br>4 | 1.40561E-<br>05 | 20171.411<br>4 |
| 116.5       | 4150 | 0.29305 | 1.1223<br>3 | 434.3666667 | 47.518952  | 20640.648<br>8 | 1.41977E-<br>05 | 20253.636<br>6 |
| 115.93<br>1 | 4200 | 0.2949  | 1.1217<br>9 | 439.6       | 47.2868637 | 20787.305<br>3 | 1.41865E-<br>05 | 20397.543<br>3 |
| 115.03<br>4 | 4250 | 0.29715 | 1.1245<br>6 | 444.8333333 | 46.9209882 | 20872.019<br>6 | 1.42368E-<br>05 | 20480.669<br>2 |
| 114.39<br>1 | 4300 | 0.3022  | 1.1227<br>8 | 450.0666667 | 46.6587162 | 20999.532<br>9 | 1.43908E-<br>05 | 20605.791<br>6 |
| 114.01<br>6 | 4350 | 0.30605 | 1.1194<br>3 | 455.3       | 46.5057582 | 21174.071<br>7 | 1.4454E-05      | 20777.057<br>9 |
| 113.87<br>1 | 4400 | 0.3092  | 1.1198<br>6 | 460.5333333 | 46.4466144 | 21390.214<br>2 | 1.44552E-<br>05 | 20989.147<br>7 |

|             |      |         |             |             |            |                |                 |                |
|-------------|------|---------|-------------|-------------|------------|----------------|-----------------|----------------|
| 113.98<br>5 | 4450 | 0.3099  | 1.1187<br>3 | 465.7666667 | 46.4931137 | 21654.942<br>6 | 1.43108E-<br>05 | 21248.912<br>4 |
| 113.30<br>6 | 4500 | 0.31445 | 1.1156<br>3 | 471         | 46.2161577 | 21767.810<br>3 | 1.44456E-<br>05 | 21359.663<br>8 |
| 113.07<br>4 | 4550 | 0.3171  | 1.1095<br>3 | 476.2333333 | 46.1215277 | 21964.608<br>9 | 1.44369E-<br>05 | 21552.772<br>5 |
| 112.19<br>5 | 4600 | 0.3194  | 1.1056<br>9 | 481.4666667 | 45.7629942 | 22033.356<br>3 | 1.44962E-<br>05 | 21620.230<br>8 |
| 111.06<br>1 | 4650 | 0.32055 | 1.0978<br>2 | 486.7       | 45.3004492 | 22047.728<br>6 | 1.45389E-<br>05 | 21634.333<br>7 |
| 109.97<br>3 | 4700 | 0.3207  | 1.0955<br>8 | 491.9333333 | 44.856667  | 22066.489<br>7 | 1.45333E-<br>05 | 21652.743      |
| 108.65<br>4 | 4750 | 0.32485 | 1.0882<br>7 | 497.1666667 | 44.3186628 | 22033.761<br>8 | 1.47433E-<br>05 | 21620.628<br>8 |
| 107.07<br>6 | 4800 | 0.32455 | 1.0839<br>6 | 502.4       | 43.6750155 | 21942.327<br>8 | 1.4791E-05      | 21530.909<br>1 |
| 105.24      | 4850 | 0.3257  | 1.0822<br>1 | 507.6333333 | 42.9261331 | 21790.736      | 1.49467E-<br>05 | 21382.159<br>7 |
| 103.63<br>2 | 4900 | 0.3277  | 1.0846      | 512.8666667 | 42.2702492 | 21679.001<br>8 | 1.5116E-05      | 21272.520<br>5 |
| 102.33<br>5 | 4950 | 0.32845 | 1.0882<br>3 | 518.1       | 41.7412185 | 21626.125<br>3 | 1.51876E-<br>05 | 21220.635<br>4 |
| 101.10<br>6 | 5000 | 0.3287  | 1.0868<br>7 | 523.3333333 | 41.2399241 | 21582.227      | 1.52301E-<br>05 | 21177.560<br>2 |
| 99.314<br>9 | 5050 | 0.32985 | 1.0891      | 528.5666667 | 40.5093559 | 21411.895<br>2 | 1.5405E-05      | 21010.422<br>2 |
| 97.581<br>5 | 5100 | 0.3297  | 1.0918<br>5 | 533.8       | 39.8023229 | 21246.479<br>9 | 1.55179E-<br>05 | 20848.108<br>5 |
| 95.848<br>6 | 5150 | 0.33095 | 1.0940<br>7 | 539.0333333 | 39.0954938 | 21073.774<br>3 | 1.57044E-<br>05 | 20678.641      |
| 94.803<br>3 | 5200 | 0.3338  | 1.0934<br>6 | 544.2666667 | 38.6691284 | 21046.317<br>6 | 1.58603E-<br>05 | 20651.699<br>2 |
| 93.097<br>6 | 5250 | 0.3313  | 1.0880<br>4 | 549.5       | 37.9733939 | 20866.379<br>9 | 1.58772E-<br>05 | 20475.135<br>3 |
| 91.788<br>6 | 5300 | 0.3324  | 1.0833<br>9 | 554.7333333 | 37.4394685 | 20768.921<br>1 | 1.60047E-<br>05 | 20379.503<br>9 |
| 90.593<br>8 | 5350 | 0.3308  | 1.0800<br>7 | 559.9666667 | 36.9521239 | 20691.957<br>6 | 1.59869E-<br>05 | 20303.983<br>4 |

|             |      |        |             |             |             |                |             |                |
|-------------|------|--------|-------------|-------------|-------------|----------------|-------------|----------------|
| 89.637<br>4 | 5400 | 0.3388 | 1.0789<br>5 | 565.2       | 36.56201986 | 20664.853<br>6 | 1.6395E-05  | 20277.387<br>6 |
| 88.925<br>6 | 5450 | 0.3438 | 1.0792<br>3 | 570.4333333 | 36.27168513 | 20690.578<br>3 | 1.66163E-05 | 20302.629<br>9 |
| 88.647<br>4 | 5500 | 0.3488 | 1.0836<br>6 | 575.6666667 | 36.15821076 | 20815.076<br>6 | 1.67571E-05 | 20424.793<br>9 |

## Graphs:



The SFC varies as it does with the engine speed. Some reasons why this is true are because of various factors like the setting of the throttle, the load, engine design, thermal efficiency, et cetera.


The throttle setting can cause varies as the engine produces less power but uses less fuel when operating at lower engine speeds (lower throttle settings). This is so that the engine's intake of air-fuel mixture can be regulated by the throttle. Less fuel is needed to maintain the reduced power output at lower speeds.

The load can also affect this as the need for engine load has a big impact on SFC. Because there is a greater requirement for power output at higher engine speeds and loads, fuel

consumption may rise. On the other hand, as the engine runs closer to its maximum efficiency point with reduced loads, fuel consumption may drop.

Similarly, the engine design can affect this as at different speeds, different engine designs have different properties. The SFC characteristics of naturally aspirated engines may differ from those of turbocharged engines. Furthermore, engines with lift and variable valve timing can maximize fuel efficiency at different velocities.

Thermal efficiency also plays an important role in causing the SFC to vary from engine speed as Engine speed can affect the engine's thermal efficiency, which is defined as the ratio of useful work output to fuel-derived heat. Engines may have optimal speed ranges within which they run most effectively, resulting in lower SFC.




The torque can vary regarding engine speed due to several factors such as the engine design, load, intake and exhaust system, frictional losses and so on.

Design elements including bore, stroke, valve timing, compression ratio, and induction system design have a significant impact on an engine's torque characteristics. Variations in engine designs result in varying torque curves; engines with low-end torque, or more torque produced at low speeds, and high-end torque, or more torque produced at higher speeds.

Engine speed and load variables affect the torque needed to overcome resistance or complete a task. More torque is usually needed when the engine is under more load, so to maintain or increase speed, the engine may need to run faster.

The engine's capacity to breathe effectively at various speeds is influenced by the design of the intake and exhaust systems, which includes the size and form of headers, mufflers, and intake and exhaust ports. To maximize torque across the engine's working range, ideal airflow is necessary.

Mechanical losses that impact torque output are partly caused by friction between moving parts, including gears, piston rings, and bearings. The torque output decreases as engine speed increases due to an increase in frictional losses. Similarly, engine speed can change and impact torque output due to pumping losses caused by the engine's intake and exhaust systems.



The brake power is measured at the output shaft and can vary from the engine speed due to certain criteria. Some of these are the valve timing, friction, load as well as the combustion efficiency.

The opening and closing of intake and exhaust valves can be optimized by engines with variable valve timing and lift systems to increase power production at a variety of engine

speeds. Power output can be raised by optimizing the lift and timing of the valves to boost volumetric efficiency.

Power losses that impact power output are caused by friction between moving parts and mechanical losses in the engine. The net power output of the engine decreases as engine speed increases due to an increase in frictional losses.

The engine speed and load conditions affect how much power is needed to overcome resistance or complete a task. In order to maintain or accelerate at a given speed, increasing the load on the engine usually demands more power, which may call for faster engine speeds.

The efficiency of the combustion process within the engine cylinders can be influenced by engine speed. At some rates, the combustion process may be more efficient, resulting in the production of greater power from the same amount of fuel.

## **Conclusion:**

The dynamometer is principled to transfer accurate data to the computer with the help of the sensors attached. The values derived are precise, making this dynamometer useful in day-to-day experiments.

Specific fuel consumption (SFC) generally varies with engine speed due to a combination of factors related to engine design, mechanical inefficiencies, combustion efficiency, and current workload circumstances. Comprehending these components is essential to optimizing engine performance and fuel efficiency in various operating scenarios. An engine's torque output changes as its speed is a result of a complex interplay between various engine architecture, intake and exhaust system configurations, variable valve timing adjustments, forced induction, fuel and ignition timing synchronization, friction and mechanical resistances, and operating workload.

Comprehending these components is essential for maximizing engine performance in many operating environments. Because of a variety of factors, such as combustion efficiency, the efficiency of the intake and exhaust systems, the impact of forced induction, frictional and mechanical resistance, the current workload, and the coordination of fuel and ignition

timing, the brake power generated by an engine also varies with engine speed. Comprehending these components is essential to maximizing engine performance in a range of operating environments.

**References:**

Abdullah, Nik Rosli, et al. "Effect of Injection Pressure with Split Injection in a v6 Diesel Engine." [Www.sae.org](http://www.sae.org), 13 Sept. 2009, [www.sae.org/publications/technical-papers/content/2009-24-0049/](http://www.sae.org/publications/technical-papers/content/2009-24-0049/). Accessed 17 Mar. 2024.