


FX TRIGGER - INSTRUCTIONS FOR USE

1. CONNECT USB CABLE

Connect the small end of the USB cable to the Makey Makey Board (as shown in photo below). Connect the other end to your computer.




2. DOWNLOAD SOUNDPLANT SOFTWARE

Download and install Soundplant 47 onto your computer: <https://soundplant.org/>

3. LOAD THE SAMPLES INTO SOUNDPLANT

Open the file called **FX.keymap** in Soundplant. This will load a saved template with some samples already mapped to the trigger keys.



4. PLAY THE TRIGGER KEYS

Now when you play the Lego trigger keys, you will hear the samples assigned to each key. The lego keys correspond to the following keys:

Grey Lego Key = Left

Red Lego Key = Up

Green Lego Key = Right



You can also drag other samples (circled above in red) onto any of the Left, Up, Right keys to change the sample to a different sound.

RECORDING INTO A DAW

If you would like to record sounds into Logic (or another DAW) follow the instructions below.

1. DOWNLOAD SOUNDFLOWER

Download and install Soundflower into your computer:

<https://github.com/mattingalls/Soundflower>

2. SET OUTPUT IN SOUNDFLOWER

Open the preferences pane and change audio output to Soundflower 2ch

3. SET INPUT IN LOGIC

Open the audio preferences and change audio input to Soundflower 2ch. Leave the output set to Built In Audio. Create a new audio track and hit record. You should now be able to record sounds from Soundplant into Logic.