

UWTSD PRINTED TEXTILE WORKSHOP & DYE LAB NOTES

Technique

Reactive print paste

Suitable fabrics and fibres

All cellulose + protein fibres (appropriate for cellulose)

Method

5% reactive sage green - screen print - dry + fix

Fixation

150°C for 5 minutes under a heatpress
wash with boiling hot or tap hot water.

Notes

Works on dyed and undyed cloth.
dyed colour will react with the dye paste colour.

Technique

Suitable fabrics and fibres

Method

Fixation

Notes